

# DELKOtaper

## USAGE INSTRUCTIONS

**DT1:** Open the door and place the tape onto the tape roll holder. Feed tape through the rear gate, along the top of the DELKOtaper and through the front gate past the applicator.

**DT2:** Mix compound to a pourable consistency with the DELKOturbo mixing paddle.

**DT3:** Pour compound into the DELKOtaper and close the door. Alternatively, use the DELKOpump to draw the compound out of the bucket and pump into the DELKOtaper.

**DT4:** Adjust the hook & loop side strap to desired comfort.

**DT5:** Adjust the mud control dial to desired thickness.

**DT6: WHEN TAPING FLAT JOINTS:** open the door and remove the Delko Internal Applicator. Replace with the Flat Applicator. Hold the end of the tape and press the applicator against the joint, pull along the joint until complete. Cut the tape with a DELKOblade taping knife, press the DELKOblade against the tape and twist the DELKOtaper to cut the tape.

**DT7:** Run over the tape with your DELKOblade to smooth the joint and remove any excess compound.

**DT8: WHEN TAPING INTERNAL CORNER JOINTS:** open the door and remove the Flat Applicator. Replace with the Delko Internal Applicator. Hold the end of the tape and press the Delko Internal Applicator into the internal corner, pull along the joint until complete. Cut the tape by pressing the square point of your DELKOblade into the corner of the internal and twist the DELKOtaper away from the DELKOblade.

**DT9:** Run over each side of the tape with your DELKOblade to smooth the internal and remove any excess compound.

**DT10:** When finished, remove the applicator and mud control knob then rinse with water.



**Also available from Delko Tools:**

**DELKO**holster **ZÜNDER**  
DELKO

**DELKO**turbo **DELKO**blade **DELKO**pump

Delko® Internal Applicator Attachment: U.S. Patent No. 8,955,573 Canadian Patent No. 2792006 NZ Patent No. 600968 AU Patent No. 2011213482 Patent Pending – Europe. The Delko® Holster: Patent No. D841321. The Delko® Holster is a registered design. Registration reference 201812948 & 005287034-0001. DELKO and Zünder are registered trademarks of Delko Tools.

**DELKO**tools

delkotools.com.au

